

# Mégane Laguna

**N.T. 3266A**

---

**XA0N - X56J**

---

## **Special features of F9Q 710 and 736 engines**

***This note cancels and replaces Technical Note N.T. 3181A***

---

**For parts which are not described in this note refer to Workshop Repair Manual  
M.R. 312 or to Workshop Repair Manual M.R. 307 and to Technical Notes 2887A  
(Mégane) or 2938A (Laguna)**

---

**77 11 205 712**

**JUNE 1999**

**Edition Anglaise**

---

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed".

All copyrights reserved by Renault.


Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

## Contents

	Pages
<b>12 FUEL MIXTURE</b>	
Air intake	12-1
<b>13 DIESEL EQUIPMENT</b>	
Specifications	13-1
Engine immobiliser function	13-3
Accelerator potentiometer	13-4
Centralised Coolant Temperature Management	13-5
Allocation of computer tracks	13-6
Wiring diagram	13-7
<b>Fault finding</b>	
Introduction	13-12
Interpretation of faults	13-13
Assistance	13-41
Conformity check	13-42
Customer complaints	13-46
Fault charts	13-47

---


AIR INTAKE CIRCUIT DIAGRAM (MEGANE)



16009R1

- 1 Air-air exchanger
- 2 Air filter
- 3 Flowmeter
- 4 Inlet manifold
- 5 Turbocharger
- A Air inlet

AIR INTAKE CIRCUIT DIAGRAM (LAGUNA)



16353R

- 1 Air-air exchanger
- 2 Air filter
- 3 Flowmeter
- 4 Inlet manifold
- 5 Turbocharger
- A Air inlet

# DIESEL EQUIPMENT Specifications

# 13

Vehicle	Gearbox	Engine							Emission control standard
		Type	Index	Bore (mm)	Stroke (mm)	Cubic capacity (cm <sup>3</sup> )	Compression ratio	Catalytic converter	
XA0N X56J	JB3 JC5	F9Q	736 710	80	93	1870	18.3/1	◇ C58	EU 96

ENGINE SPEED (rpm)			OPACITY OF SMOKE	
Idle speed	Max. unladen	Max. loaded	Approval value	Legal maximum
850 ± 25	4800 ± 250	4750 ± 250	1.4 m <sup>-1</sup> (43.5 %)	3 m <sup>-1</sup> (71 %)

DESCRIPTION	BRAND/TYPE	SPECIAL NOTES
Injection pump	BOSCH VE 4/11 E2125 R803-1	Rotary pump associated with a computer which controls: - the pump (advance and flow), - the cold start system, - the EGR.
Pump setting, obtaining of Top Dead Centre by means of an 8 mm Ø pin (Mot. 1054)		Pump piston lift: <b>0.32 ± 0.02 mm</b>
Nozzle holder	BOSCH KBEL 58 P147 (cylinders 1-2-3) KBEL 58 P146 (cylinder 4)	Resistance of calibrated injector: <b>100 ± 10 Ω to 20 °C</b>
Injectors	DSL A 145 P619	Calibration pressure: <b>200 ± 12 bars</b>
Fuel filter	BOSCH	The filter is fitted with an electric diesel heater.
EGR solenoid valve	SIEMENS	Voltage: <b>12 Volts</b> Resistance: <b>16.5 ± 0.5 Ω</b>
Delivery tubes	-	Internal diameter: <b>1.8 mm</b> Length: <b>360 mm</b>
Pre-heating unit	NAGARES BRE 6/12	With pre-post heating function controlled by injection computer
Heater plugs	BERU	Tightening torque: <b>1.5 daN.m</b> Voltage: <b>12 Volts</b> Resistance: <b>0.6 ± 0.1 Ω</b> - Heater plug disconnected
Fuel shut-off	-	Resistance: <b>0.8 Ω</b>

# DIESEL EQUIPMENT Specifications

# 13

DESCRIPTION	BRAND/TYPE	SPECIAL NOTES
Turbocharger	GARRETT	Calibration: <b>1300 ± 10 mbars</b> for a pin travel of <b>2.4 ± 0.02 mm</b>
Computer	BOSCH/MSA 15.5	68 tracks with pressure sensor incorporated
Injection	-	Direct
Flowmeter	SIEMENS	Air flow meter Air sensor incorporated <ol style="list-style-type: none"> <li>1. Air temperature</li> <li>2. Common earth</li> <li>3. 5 V reference</li> <li>4. + Battery</li> <li>5. Flow signal</li> <li>6. Earth</li> </ol>
Top Dead Centre sensor	MGI	Resistance ≈ <b>760 Ω at 20 °C</b>
Flow slide valve	BOSCH (incorporated in the pump)	Resistance between tracks 4 and 7 of the pump connector between <b>0.4 and 1 Ω at 20 °C</b>
Flow slide valve position sensor	BOSCH (incorporated in the pump)	Resistance between tracks: - 1 and 3 of the pump connector between <b>4.9 and 6.5 Ω at 20 °C</b> , - 3 and 2 of the pump connector between <b>4.9 and 6.5 Ω at 20 °C</b> .
Advance solenoid valve	BOSCH (incorporated in the pump)	Resistance between tracks 1 and 2 of the solenoid valve connector between <b>14.3 and 17.3 Ω at 20 °C</b> .
Accelerator pedal potentiometer	CTS	Single track potentiometer+ no-load switch
Immersion heater	-	Resistance: <b>0.6 ± 0.1 Ω at 20 °C</b> - Connector disconnected
Diagnostics	Diagnostic equipment (except XR25)	

Temperature in °C (± 1°)	0	20	40	80
Coolant temperature sensor (Resistance in Ohms)	5290 to 6490	2400 to 2600	1070 to 1270	300 to 450
Diesel temperature sensor (Resistance in Ohms)	5290 to 6490	2200 to 2600	1020 to 1270	300 to 450

This vehicle is fitted with an engine immobiliser system which is controlled by a random rolling code key recognition system.

**REPLACEMENT OF AN INJECTION COMPUTER**

The injection computers are supplied without a code but they can all be programmed with one.

When a computer is replaced, it must be programmed with the code of the vehicle and the correct operation of the engine immobiliser function must be checked.

To do this, simply switch on the ignition for a few seconds without starting the engine then switch it off. With the ignition off, the engine immobiliser function comes into operation after approximately 10 seconds (the red engine immobiliser warning light flashes).

**WARNING:**

**In the case of this engine immobiliser system, the computer retains the engine immobiliser code for life.**


**Furthermore, this system does not have a security code.**

**Consequently, it is prohibited to carry out tests using computers borrowed from the warehouse or another vehicle which must then be returned.**

**It will not be possible to erase the code.**


### Allocation of tracks:

- 1 No-load switch
- 2 Not used
- 3 Track signal
- 4 Earth
- 5 5 V supply
- 6 No-load switch



15759R1

No-load value= 0 %  
Full-load value= 100 %



16367R

### REMOVAL OF THE POTENTIOMETER (A)


Remove the unit located under the master cylinder (Mégane).

Unhook the accelerator cable from the unit. The potentiometer is distributed at the Parts Department with the unit.

### REFITTING

Proceed in the reverse order to removal.

It is essential to validate the repair using the diagnostic equipment.




15760S

**NOTE:** an accelerator pedal position potentiometer fault results in a modified idle or operating speed.



### CCTM



- 244 Coolant temperature sensor (injection and coolant temperature indication on the instrument panel).  
3-way sensor, 2 for the coolant temperature information and 1 for the indication on the instrument panel.

This system enables the cooling fan to be controlled by the injection computer. It consists of a single coolant temperature sensor which is used by the injection, the fan, the temperature indicator and the temperature warning light on the instrument panel.

### OPERATION

Sensor 244 enables:

- the coolant temperature to be indicated on the instrument panel,
- the injection computer to be informed of the engine coolant temperature.

Depending on the coolant temperature, the injection computer controls:

- the injection system,
- the fan relay:
  - the fan assembly is controlled at low speed if the coolant temperature exceeds **99 °C** and stops when the temperature falls below **96 °C**,
  - the fan assembly is controlled at high speed if the coolant temperature exceeds **102 °C** and stops when the temperature falls below **99 °C**,
  - the fan assembly may be controlled for the AC and in the event of a temperature sensor failure.

Only the fan low speed is operational on vehicles which are not fitted with AC.

### COOLANT TEMPERATURE WARNING LIGHT

The warning light is controlled by the computer.

It is controlled when the temperature exceeds **105° C**.

# DIESEL EQUIPMENT

## Allocation of computer tracks


13

Track	Description	Track	Description
1	Earth	35	Heated windscreen signal
2	TDC signal output	36	Not used
3	Fan assembly low speed command	37	AC information
4	Flow actuator command	38	+ after ignition
5	Flow actuator command	39	Not used
6	Fan assembly high speed command	40	Not used
7	Flow slide valve position sensor input	41	Not used
8	TDC sensor signal input	42	Main relay command output
9	Not used	43	Vehicle speed signal input
10	Not used	44	Brake switch signal input (track 2)
11	Needle lift sensor earth	45	+ before ignition
12	Needle lift signal input	46	Earth
13	Air flow signal input	47	Immersion heaters command (relay 2)
14	Coolant temperature signal input	48	Coolant temperature warning light output
15	Pedal position sensor signal input	49	Flow actuator command
16	Reverse gear switch (depending on version)	50	Pre-heating relay command
17	Clutch switch signal input (Laguna)	51	Advance solenoid valve control
18	Not used	52	Flow slide valve position sensor
19	5 Volts flowmeter supply	53	Fuel shut-off command
20	Brake switch signal input (track 1)	54	Pre-heating warning light output
21	Sensors earth	55	Pedal position sensor
22	Not used	56	Not used
23	+ before ignition	57	Pedal position sensor
24	Earth	58	Not used
25	EGR valve command	59	Engine immobiliser
26	Fault warning light command	60	Not used
27	Immersion heaters command (relay 1)	61	Diagnostics
28	AC authorisation output	62	Not used
29	Flow sensor energising	63	Fuel temperature signal
30	Pre-heating relay diagnostic connection	64	Intake air temperature signal
31	Not used	65	No-load switch signal
32	Fuel consumption information	66	Diagnostics
33	Sensors earth	67	Not used
34	Not used	68	+ before ignition

**PARTS LIST**


120	Injection computer
149	Top Dead Centre sensor
155	Reverse gear switch
160	Brake switch
163	Starter
225	Diagnostic socket
234	Fan assembly high speed relay
244	Coolant temperature sensor
247	Instrument panel
257	Pre-heating unit
273	Top Dead Centre sensor
299	Relay accessory fuse board
319	AC control panel
335	Fan assembly low speed relay
398	EGR valve
419	AC control panel
450	Diesel heater relay
503	Engine immobiliser
597	Engine compartment fuse box
645	Passenger compartment connection unit
647	Heated windscreen
675	Clutch pedal switch
676	Accelerator potentiometer
680, 681, 682, 683	Pre-heating heater plugs
711	Diesel pump
721	ABS ECU transponder
738	Needle lift sensor
756	ECU transponder
777	Fuse board
799	Air flowmeter with air temperature sensor
898	Immersion heaters
921	Accelerator potentiometer
927	Shock sensor
952	Fuel shut-off and advance actuator electronics
983	Injection ECU transponder supply relay
1016	Passenger compartment fuse box
1047	Injection relay
1049	Immersion heaters relay

# DIESEL EQUIPMENT Wiring Diagram




# DIESEL EQUIPMENT

## Wiring diagram







### CONDITIONS FOR THE APPLICATION OF THE CHECKS DEFINED IN THIS FAULT FINDING SECTION

In this fault finding section, each fault is interpreted for a particular type of storing (fault present, fault stored, fault present or stored).

The checks defined for dealing with each fault therefore are to be applied to the vehicle only if the fault is interpreted for the type of fault indicated by the diagnostic equipment.

If a fault is interpreted in this fault finding section only if it is shown to be "present", the application of the fault finding procedure when the fault is only "stored" will not enable the origin of the storing of this fault to be located. In this case, only a check of the wiring and the connections of the component in question should be carried out.

If a fault is interpreted when it is shown to be "stored", the conditions for confirming the actual presence of the fault (and the necessity of applying the fault finding procedure) will be given in the "Notes" box or at the beginning of the interpretation of the fault.

**NOTE :** The ignition must be switched off before the diagnostic equipment is switched on.  
The characterisation of a stored fault is always limited to dEF even if the failure is present but the conditions under which it is taken into account are not met (it is not possible to obtain a 1.dEF or a co.0 stored).

### ESSENTIAL EQUIPMENT FOR CARRYING OUT WORK ON THE BOSCH ELECTRONIC INJECTION SYSTEM

- Diagnostic equipment (except XR25).



<b>DF001 present or stored</b>	<u>Computer fault</u>
--	-----------------------

<b>NOTES</b>	None
--------------	------

If the fault is only stored, erase the computer memory. Switch off the ignition then switch it on again to reinitialise the computer.

Change the computer if the fault occurs again.

If the fault is present, change the computer.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
-------------------------	--

<b>DF002 present or stored</b>	<p><u>Coolant temperature sensor circuit</u></p> <p>dEF : Fault stored co.1 : Open circuit or short circuit to 12 volts cc.0 : Short circuit to earth 1.dEF : Operating temperature consistency</p>
--	---

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Start the engine and warm it up to try to confirm the presence of a fault.  
If the bargraph shows that a fault is present, apply the fault finding procedure associated with the type of fault indicated.

If it is not possible to confirm the presence of a fault on the vehicle, check the coolant temperature sensor circuits as a precaution.

Investigate the cause of a possible increase in the engine coolant temperature above the normal operating range (cooling circuit fault, conformity of the temperature sensor, engine compartment cooling, ...).

<b>co.1</b>	<b>NOTES</b>	<p>If fault DF021 co.1 is also indicated, look for an open circuit of the sensors earth (track 33 of the computer connector). Also check the condition and securing of the engine earth strap and the MH engine earth.</p>
-------------	--------------	--

Ensure the continuity and insulation from + **12 volts** of the connection between **track 14** of the computer connector and **track 3** of the coolant temperature sensor connector.

Ensure the continuity of the connection between **track 33** of the computer connector and **track 2** of the coolant temperature sensor connector.

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the coolant temperature sensor.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<p><b>DF002</b></p> <p>CONT</p>	
---------------------------------	--

<b>cc.0</b>	<b>NOTES</b>	None
-------------	--------------	------

Ensure the insulation from earth of the connection between **track 14** of the computer connector and **track 3** of the coolant temperature sensor connector.

Check whether there is a short circuit on the sensor circuit (or the sensor ) (resistance approximately 300 to 450 ohms at 80 °C / 2400 to 2600 ohms at 20 °C).

Check the connections on both connectors of the connection.

---

If the fault persists following these checks, change the coolant temperature sensor.

<b>1.dEF</b>	<b>NOTES</b>	None
--------------	--------------	------

Measure the line resistances of the following connections:

- Between **track 14** of the computer connector and **track 3** of the coolant temperature sensor connector.
- Between **track 33** of the computer connector and **track 2** of the coolant temperature sensor connector.

Carry out the operations necessary if there is an abnormally high resistance.

---

If the fault persists following these checks, change the coolant temperature sensor.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---

<b>DF003 present or stored</b>	<p><u>Load potentiometer circuit</u></p> <p>dEF : Fault stored          1.dEF : General consistency          1.cc.1 : CC to 12 volts of the 5 volt supply          1.co.0 : CO or CC to earth of the 5 volt supply          2.cc.1 : CC sensor or CC to 12 volts of the signal</p>
--	--

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Press the accelerator pedal to the full-load position to try to confirm the presence of a fault. If the fault is shown to be present, apply the fault finding procedure associated with the type of fault indicated.

If it is not possible to confirm the presence of a fault on the vehicle, check the load potentiometer circuits as a precaution.

<b>1.dEF</b>	<b>NOTES</b>	None
--------------	--------------	------

Ensure that the "pedal not pressed" position recognition switch is operating correctly by means of status **ET016** "No-load switch information" (Open switch between **tracks 1 and 6** of the load potentiometer connector). Ensure that earth is present on **track 1 (F9Q 710)**, and on **track 6 (F9Q 736)**.

Ensure the continuity and insulation from earth of the connection between **track 65** of the computer connector and **track 6 (F9Q 710)**, **track 1 (F9Q 736)** of the load potentiometer connector.

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the load potentiometer.

<b>1.cc.1 / 1.co.0</b>	<b>NOTES</b>	None
------------------------	--------------	------

Ensure the continuity and insulation from earth of the connection between **track 15** of the computer connector and **track 3** of the load potentiometer connector.

Ensure the continuity and insulation from **+12 volts** of the connection between **track 57** of the computer connector and **track 5** of the load potentiometer connector.

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the load potentiometer.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---

<p><b>DF003</b></p> <p>CONT</p>	
---------------------------------	--

<b>2.cc.1</b>	<b>NOTES</b>	None
---------------	--------------	------

<p>Ensure the continuity of the connection between <b>track 55</b> of the computer connector and <b>track 4</b> of the load potentiometer connector.</p> <p>Ensure the insulation from <b>12 volts</b> of the connection between <b>track 15</b> of the computer connector and <b>track 3</b> of the load potentiometer connector. Also ensure the insulation of this connection from the connection between <b>track 57</b> of the computer connector and <b>track 5</b> of the load potentiometer connector (+5 volts potentiometer).</p> <p>Check for a possible potentiometer short circuit (between tracks 4 and 5 of the 6-way connector) or a short circuit of its supply.</p> <p>Check the connections on both connectors of the connection.</p>
<p>If the fault persists following these checks, change the load potentiometer.</p>

<b>2.co.0</b>	<b>NOTES</b>	None
---------------	--------------	------

<p>Ensure the continuity and insulation from earth of the connection between <b>track 57</b> of the computer connector and <b>track 5</b> of the load potentiometer connector.</p> <p>Check the connections on both connectors of the connection.</p>
<p>If the fault persists following these checks, change the load potentiometer.</p>

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---

<b>DF004 stored</b>	<p><u>Vehicle speed sensor circuit</u></p> <p>dDEF : Fault stored 1.dDEF : Signal frequency too high 2.dDEF : Maximum speed exceeded 3.dDEF : Consistency between flow and vehicle speed</p>
-------------------------	--

<b>NOTES</b>	None
--------------	------

<b>dDEF</b>	<b>NOTES</b>	None
-------------	--------------	------

Carry out a road test to try to confirm the presence of a fault.

If the fault is shown to be present, apply the fault finding procedure associated with the type of fault indicated.

If it is not possible to confirm the presence of a fault on the vehicle, check the vehicle speed sensor circuits as a precaution (signal interference).

<b>1.dDEF / 2.dDEF 3.dDEF</b>	<b>NOTES</b>	None
-----------------------------------	--------------	------

**Is the vehicle speed information present on the instrument panel?**

<b>YES</b>	<p>Check the engine management computer connections. Ensure the continuity between <b>track 43</b> of the engine management computer connector and the source of the vehicle speed information (tachometer sensor or ABS computer).</p>
------------	---

<b>NO</b>	<p><b>A : Vehicle speed information via ABS computer.</b> Check the ABS computer connector connections. Ensure the continuity of the connection between <b>track 43</b> of the engine management computer connector and the ABS computer connector. Ensure the insulation of all the connections relating to vehicle speed information reception.</p> <p><b>B : Vehicle speed information via tachometer sensor.</b> Check the vehicle speed sensor connections. Ensure that the speed sensor is supplied correctly. Ensure the continuity and insulation of the connection between <b>track 43</b> of the engine management computer connector and <b>track B1</b> of the sensor connector. If the fault persists following these checks, change the vehicle speed sensor.</p>
-----------	---

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<b>DF005</b>  <b>Present</b>  <b>or stored</b>	<u>Needle lift sensor circuit</u>  DEF : Stored fault 1.dEF : Open circuit or short circuit to 12 volts 2.dEF : Short circuit to earth 3.dEF : Static consistency 4.dEF : Dynamic consistency 5.dEF : Over-revving
--	---

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Start the engine to try to confirm the presence of a fault.  
 If the bargraph shows that a fault is present, apply the fault finding procedure associated with the type of fault indicated.  
 If it is not possible to confirm the presence of a fault with the engine running, carry out a road test to confirm a possible signal consistency fault.

If it is not possible to confirm the presence of a fault on the vehicle, check the needle lift sensor circuits as a precaution (signal interference).

<b>1.dEF / 2.dEF</b>	<b>NOTES</b>	None
----------------------	--------------	------

Measure the resistance of the needle lift sensor at its connector.  
 Change the calibrated injector if the resistance is not **100 ± 10 ohms at 20°C**.  
 Ensure the continuity of the following connections:  
 - Between **track 12** of the computer connector and **track 1** of the needle lift sensor connector.  
 - Between **track 11** of the computer connector and **track 2** of the needle lift sensor connector.  
 Check the connections on both connectors of the connection.

Ensure the insulation of the connection between **track 12** of the computer connector and **track 1** of the needle lift sensor connector.  
 Ensure the insulation between the 2 lines of the needle lift sensor.

Also check the condition of the wiring between the sensor connector and the sensor.

If the fault persists following these checks, change the calibrated injector.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
---------------------	---

<p><b>DF005</b></p> <p>CONT</p>	
---------------------------------	--

<b>3.dEF</b>	<b>NOTES</b>	None
--------------	--------------	------

Check the condition of the injector and its fuel supply (injector seized, pipe kinked,...).

If the fault persists following these checks, change the calibrated injector (sensor faulty).

<b>4.dEF / 5.dEF</b>	<b>NOTES</b>	None
----------------------	--------------	------

These faults are taken into account in the event of needle lift sensor signal interference.

Check the condition of the sensor wiring and look for a circuit insulation fault (earthing of the shielding,...).

If the fault persists following these checks, change the calibrated injector.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---



<b>DF006</b> <b>present</b> <b>or</b> <b>stored</b>	<u>Advance solenoid valve circuit</u> DEF : Fault stored co.0 : Open circuit or short circuit to earth cc.1 : Short circuit to 12 volts 1.dEF : Advance regulation deviation
--	--

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Start the engine to try to confirm the presence of a fault.  
 If the fault is shown to be present, apply the fault finding procedure associated with the type of fault indicated.  
 If it is not possible to confirm the presence of a fault with the engine running, carry out a road test (1.dEF indicated only if the engine speed > 1500 rpm).

If it is not possible to confirm the presence of a fault on the vehicle, check the advance solenoid valve circuits as a precaution.

<b>co.0</b>	<b>NOTES</b>	None
-------------	--------------	------

Measure the resistance of the advance solenoid valve at its connector.  
 Change the advance solenoid valve if the resistance is not approximately **15 ohms** (14.3 to 17.3 ohms at 20°C).  
 Ensure the continuity and insulation from earth of the connection between **track 51** of the computer connector and **track 1** of the advance solenoid valve connector.  
 Ensure that there is a + **after relay supply on track 2** of the corrector connector, wiring end.  
 Check the connections on both connectors.

If the fault persists following these checks, change the advance solenoid valve.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
---------------------	---

<p><b>DF006</b></p> <p>CONT</p>	
---------------------------------	--

<p><b>cc.1</b></p>	<p><b>NOTES</b></p>	<p>None</p>
--------------------	---------------------	-------------

Measure the resistance of the advance solenoid valve at its connector.  
 Change the advance solenoid valve if the resistance is not approximately **15 ohms** (short circuit).  
 Ensure the insulation from + **12 volts** of the connection between **track 51** of the computer connector and **track 1** of the advance solenoid valve connector.  
 Ensure the insulation between the advance solenoid valve control line and its + after relay supply.

If the fault persists following these checks, change the advance solenoid valve.

<p><b>1.dEF</b></p>	<p><b>NOTES</b></p>	<p>Deal with DF005 first if this is indicated as well.</p>
---------------------	---------------------	--

This fault indicates seizing of the advance solenoid valve, incorrect setting of the injection pump or a fuel supply problem.  
 It is taken into account when the advance controlled by the needle lift sensor deviates from the advance reference value requested by the computer by **more than 3°**.

- Check the condition of the needle lift sensor wire and connections.
- Check the condition of the fuel supply (filter clogged, pipe kinked, incorrect diesel in winter, ...).
- Check the pump setting and the securing of the pump pulley.

If the checks are correct, change the advance corrector.

<p><b>AFTER REPAIR</b></p>	<p>Erase the computer memory, switch off the ignition and then carry out a road test.        Complete the operation by carrying out a test using the diagnostic equipment.</p>
----------------------------	--

<b>DF014</b> <b>present</b> <b>or</b> <b>stored</b>	<u>Fuel shut-off circuit</u> dEF : Fault stored 1.dEF : Operating consistency 2.dEF : Circuit fault
--	--

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	Ensure that the engine immobiliser is released.
------------	--------------	---

Place a multimeter in voltmeter mode on the fuel shut-off supply terminal and start the "fuel shut-off" actuator command.

- If the multimeter indicates a permanent voltage of **12 volts** during the command, look for a short circuit to **12 volts** of the connection between **track 53** of the computer connector and the fuel shut-off (the command provides an alternating on/off control).

Start the engine. Switch off the ignition monitoring the diagnostic equipment display.

- If the display indicates **1.dEF** during the computer supply maintaining phase, change the fuel shut-off.

If it is not possible to obtain this display, there is no fault present on the vehicle.  
Check the fuel shut-off circuits as a precaution.

<b>2.dEF</b>	<b>NOTES</b>	None
--------------	--------------	------

Measure the resistance of the fuel shut-off at its connector.  
Change the fuel shut-off if the resistance is not approximately **7.5 ohms**.  
Ensure the continuity and insulation from earth of the connection between **track 53** of the computer connector and the fuel shut-off.  
Check the computer connections and that the fuel shut shut-off supply terminal is secured correctly.

If the fault persists following these checks, change the fuel shut-off.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
---------------------	---

<b>DF015 present</b>	<p><u>Engine immobiliser</u></p> <p>1.dEF : Engine immobiliser line fault 2.dEF : Code not programmed</p>
--------------------------	---

<b>NOTES</b>	None
--------------	------

Check the engine immobiliser function.  
Check the programming of both keys or programme them.

If the fault persists, ensure the continuity and insulation of the connection between **track 59** of the computer connector and the decoder unit (UCBIC or equivalent).

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<b>DF016 stored</b>	<p><u>Clutch switch circuit</u></p> <p>dEF : Stored fault 1.dEF : Signal not consistent</p>
-------------------------	---

<b>NOTES</b>	<p>The fault is signalled if the status of the clutch switch has not changed before reaching a speed of 60 mph (100 km/h).</p>
--------------	--

<p>Monitor status <b>ET012 clutch switch information</b> with the pedal pressed and released.</p>	
<p>Are the clutch pedal "pedal pressed" and "pedal not pressed" statuses recognised correctly?</p>	

<b>YES</b>	<p>There is no clutch switch fault.</p> <p>Carry out a simple preventive check of the fitting of the switch and the connection of its connector.</p>
------------	--

<b>NO</b>	<p>Check the condition and the setting of the clutch switch.</p> <p>Disconnect the clutch switch then check/ensure the earthing of <b>track 3</b> of the connector, wiring end.</p> <p>Check the operation of the clutch switch contact: loss of continuity between <b>tracks 1 and 3</b> when the pedal is pressed.</p> <p>Check and ensure the continuity and insulation from earth of the connection between <b>track 1</b> of the clutch switch connector and <b>track 17</b> of the computer connector.</p>
-----------	--

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---

<b>DF017 present</b>	<p><u>Main relay circuit</u></p> <p>dEF : Fault stored 1.dEF : Relay cuts off too late 2.dEF : Relay cuts off too early</p>
--------------------------	---

<b>NOTES</b>	Main relay: Position D on the engine compartment board and coil resistance approximately 65 ohms.
--------------	---

<b>1.dEF</b>
--------------

<b>NOTES</b>	The relay cuts off too late or not at all
--------------	---

Check the connections at the main relay support. Repair if necessary.  
Try another relay (note the faults stored, change the relay, erase the fault memory, switch off the ignition and wait 10 seconds, read the faults).

Check the connections at the main relay support. Repair if necessary.  
Ensure the insulation from earth of the connection between the relay support (coil earth) and **track 42** of the computer connector.  
Ensure the insulation from **+Battery** of the connection between the relay support (power output) and **tracks 23, 45 and 68** of the computer connector.

If the fault persists following these checks, change the computer (refer to the "assistance" section for this operation).

<b>2.dEF</b>
--------------

<b>NOTES</b>	The relay cuts off too early
--------------	------------------------------

Check the connections at the main relay support. Repair if necessary.  
Try another relay (note the faults stored, change the relay, erase the fault memory, switch off the ignition and wait 10 seconds, read the faults).

Check the connections at the main relay support. Repair if necessary.  
Ensure the continuity of the connection between the relay support (power output) and **tracks 23, 45 and 68** of the computer connector (wiring condition check).  
Ensure the continuity of the connection between the relay support (coil earth) and **track 42** of the computer connector (wiring condition check).

If the fault persists following these checks, change the computer (refer to the "assistance" section for this operation).

<b>AFTER REPAIR</b>
-------------------------

Erase the computer memory, switch off the ignition and then carry out a road test.  
Complete the operation by carrying out a test using the diagnostic equipment.

<b>DF019</b> <b>present</b> <b>or</b> <b>stored</b>	<p><u>Air flow sensor circuit</u></p> <p>dEF : Fault stored</p> <p>1.cc.1 : Short circuit to 12 volts of the sensor engine running</p> <p>2.cc.1 : Short circuit to 12 volts of the sensor engine not running</p> <p>1.co.0 : Open circuit or short circuit to earth of the sensor engine running</p> <p>2.co.0 : Open circuit or short circuit to earth of the sensor engine not running</p> <p>3.cc.1 : Short circuit to 12 volts of the sensor supply</p> <p>3.co.0 : Open circuit or short circuit to earth of the sensor supply</p> <p>1.dEF : Consistency</p>
--	---

<b>NOTES</b>	None
--------------	------

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Start the engine to try to confirm the presence of a fault.

- If the bargraph shows that a fault is present, apply the fault finding procedure associated with the type of fault indicated.
- If it is not possible to confirm the presence of a fault with the engine running at idle, accelerate the engine speed to more than **2000 rpm** to confirm a possible information consistency fault.

If it is not possible to confirm the presence of a fault on the vehicle, check the air flow sensor circuits as a precaution.

<b>1.cc.1 / 2.cc.1</b>	<b>NOTES</b>	If fault DF022 co.1 is indicated as well, look for an open circuit of the sensors earth (track 21 of the computer connector).
------------------------	--------------	---

Ensure the insulation from **12 volts** of the connection between **track 13** of the computer connector and **track 5** of the air flow sensor connector.

Ensure the continuity of the connection between **track 21** of the computer connector and **track 2** of the sensor connector and ensure that **-Bat** is present on **track 6** of the sensor connector (presence of a voltage > 10.5 volts after ignition between tracks 4 and 6 of the connector).

If the fault persists following these checks, change the air flow sensor.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
---------------------	--

<p><b>DF019</b></p> <p>CONT</p>	
---------------------------------	--

**1.co.0 / 2.co.0**

**NOTES**

None

Ensure the continuity and insulation from earth of the connection between **track 13** of the computer connector and **track 5** of the sensor connector and ensure that + after relay is present on **track 4** of the sensor connector (presence of a voltage >10.5 volts between tracks 4 and 6 of the connector).

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the air flow sensor.

**3.cc.1 / 3.co.0**

**NOTES**

None

Ensure the continuity and insulation of the connection between **track 19** of the computer connector and **track 3** of the sensor connector.

Ensure that there is a voltage > **10.5 volts** between **tracks 4 and 6** of the sensor connector.

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the air flow sensor.

**1.dEF**

**NOTES**

None

Check the conformity of the air intake circuit.

Check the connections on both connectors of the connection.

If the fault persists following these checks, change the air flow sensor.

**AFTER  
REPAIR**

Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.



<b>DF021 present</b>	<p><u>Fuel temperature sensor circuit</u></p> <p>co.1 : Open circuit or short circuit to 12 volts cc.0 : Short circuit to earth</p>
--------------------------	---

<b>NOTES</b>	None
--------------	------

**co.1**

<b>NOTES</b>	<p>If fault DF042 5.dEF is present also, check that the pump 7-way round connector is secured correctly.</p> <p>If fault DF002 co.1 is indicated as well, look for an open circuit of the sensors earth (track 33 of the computer connector).</p> <p>Also check the condition and securing of the engine earth strap and the MH engine earth.</p>
--------------	---

<p>Ensure the continuity and insulation from + <b>12 volts</b> of the connection between <b>track 63</b> of the computer connector and <b>track 6</b> of the pump connector.</p> <p>Ensure the continuity of the connection between <b>track 33</b> of the computer connector and <b>track 5</b> of the pump connector.</p> <p>Check the connections on both connectors of the connection.</p>
<p>If the fault persists following these checks, change the fuel temperature sensor.</p>

**cc.0**

<b>NOTES</b>	None
--------------	------

<p>Ensure the insulation from earth of the connection between <b>track 63</b> of the computer connector and <b>track 6</b> of the pump connector.</p> <p>Check whether there is a short circuit on the sensor circuit (or sensor) (resistance approximately 2.2 Kohms at 20 °C).</p> <p>Check the connections on both connectors of the connection.</p>
<p>If the fault persists following these checks, change the fuel temperature sensor.</p>

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<b>DF022 present</b>	<p><u>Air temperature sensor circuit</u></p> <p>co.1 : Open circuit or short circuit to 12 volts cc.0 : Short circuit to earth</p>
--------------------------	--

<b>NOTES</b>	The air temperature sensor is incorporated in the air flowmeter
--------------	---

<b>co.1</b>
-------------

<b>NOTES</b>	If fault DF019 2.cc.1 in indicated as well, look for an open circuit of the sensors earth (track 21 of the computer connector).
--------------	---

<p>Ensure the continuity and insulation from <b>+12 volts</b> of the connection between <b>track 64</b> of the computer connector and <b>track 1</b> of the air temperature sensor connector.</p> <p>Ensure the continuity of the connection between <b>track 21</b> of the computer connector and <b>track 2</b> of the air temperature sensor connector.</p> <p>Check the connections on both connectors of the connection.</p>
If the fault persists following these checks, change the air temperature sensor.

<b>cc.0</b>
-------------

<b>NOTES</b>	None
--------------	------

<p>Ensure the insulation from earth of the connection between <b>track 64</b> of the computer connector and <b>track 1</b> of the air temperature sensor connector.</p> <p>Check whether there is a short circuit on the sensor circuit (or the sensor) (resistance between 1070 and 1270 ohms at 40°C / 2400 and 2600 ohms at 20 °C).</p> <p>Check the connections on both connectors of the connection.</p>
If the fault persists following these checks, change the air temperature sensor.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
-------------------------	--

<b>DF023 stored</b>	<p><u>Flywheel signal sensor circuit</u></p> <p>dDEF : Fault stored 1.dDEF : Static consistency 2.dDEF : Dynamic consistency 3.dDEF : Over-revving detection</p>
-------------------------	--

<b>NOTES</b>	None
--------------	------

<b>dDEF</b>	<b>NOTES</b>	None
-------------	--------------	------

Start the engine to try to confirm the presence of a fault (or carry out a starting test).  
If the fault is shown to be present, apply the fault finding procedure associated with the type of fault indicated.  
If it is not possible to obtain an indication that the fault is present, erase the computer memory then start the engine again. Apply the fault finding procedure below if the bargraph indicates a stored fault again (dDEF).

If the fault does not occur again, check the flywheel signal sensor circuit as a precaution.

<b>1.dDEF / 2.dDEF 3.dDEF</b>	<b>NOTES</b>	None
-----------------------------------	--------------	------

Measure the resistance of the flywheel signal sensor at its connector. Change the sensor if the resistance is not **760 ohms at 20°C**.

Ensure the continuity and insulation of the following connections:

- Between **track 8** of the computer connector and **track B** of the flywheel signal sensor connector.
- Between **track 21** of the computer connector and **track A** of the flywheel signal sensor connector.

Check the insulation between these 2 connections again.

Check the connections on both connectors of the connection.

Visually check the general condition of the wiring and the wiring passage for risks of interference.

Check the positioning and condition of the sensor.  
Check the condition of the target (deformation, securing, ...).  
Check the conformity of the target: 4 slots at 90°.

If the fault persists following these checks, change the flywheel signal sensor.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<b>DF024 present</b>	<u>Atmospheric pressure sensor circuit</u> 1.dEF : Above upper limit 2.dEF : Below lower limit
--------------------------	--

<b>NOTES</b>	None
--------------	------

Change the computer.

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
-------------------------	---

<b>DF027 present</b>	<p><u>EGR solenoid valve circuit</u></p> <p>co.0 : Open circuit or short circuit to earth cc.1 : Short circuit to 12 volts</p>
--------------------------	--

<b>NOTES</b>	None
--------------	------

<b>co.0</b>	<b>NOTES</b>	None
-------------	--------------	------

<p>Measure the resistance of the EGR solenoid valve at its connector. Change the EGR solenoid valve if the resistance is not approximately <b>16.5 ohms</b>.</p> <p>Ensure the continuity and insulation from earth of the connection between <b>track 25</b> of the computer connector and <b>track 2</b> of the EGR solenoid valve connector.</p> <p>Ensure that + <b>after relay</b> is present on <b>track 1</b> of the EGR solenoid valve connector, wiring end.</p> <p>Check the connections on both connectors.</p>
<p>If the fault persists following these checks, change the EGR solenoid valve.</p>

<b>cc.1</b>	<b>NOTES</b>	None
-------------	--------------	------

<p>Measure the resistance of the EGR solenoid valve at its connector. Change the EGR solenoid valve if the resistance is not approximately <b>16.5 ohms</b> (short circuit).</p> <p>Ensure the insulation from + <b>12 volts</b> of the connection between <b>track 25</b> of the computer connector and <b>track 2</b> of the EGR solenoid valve connector.</p>
<p>If the fault persists following these checks, change the EGR solenoid valve.</p>

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<b>DF038</b> <b>present</b> <b>or</b> <b>stored</b>	<p><u>Immersion heater relays circuit</u></p> <p>dEF : Fault stored</p> <p>1.co.0 : Open circuit or short circuit to earth relay 1 circuit</p> <p>1.cc.1 : Short circuit to 12 volts relay 1 circuit</p> <p>2.co.0 : Open circuit or short circuit to earth relay 2 circuit</p> <p>2.cc.1 : Short circuit to 12 volts relay 2 circuit</p>
--	---

<b>NOTES</b>	If the vehicle is not fitted with immersion heaters, change the configuration of the computer using the "Computer configuration without immersion heaters" command.
--------------	---

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

<p>Use the "<b>Group 1 immersion heaters relay</b>" then "<b>Group 2 immersion heaters relay</b>" commands to try to confirm the presence of a fault.</p> <p>If the fault is shown to be present on completion of the command, apply the fault finding procedure associated with the type of fault indicated.</p>
<p>If it is not possible to obtain an indication that a fault is present, check the immersion heater relays wiring as a precaution.</p>

<b>1.co.0 / 2.co.0</b>	<b>NOTES</b>	None
------------------------	--------------	------

<p>Measure the resistance of the coil of the relay concerned between <b>terminals 1 and 2</b>.</p> <p>Change the relay if the resistance is not approximately <b>65 ohms</b>.</p> <p>Ensure the continuity and insulation from earth of the connection between <b>track 27</b> (relay 1) or <b>track 47</b> (relay 2) of the computer connector and <b>track 2</b> of the support of the immersion heater relay concerned.</p> <p>Ensure that + after relay is present on <b>track 1</b> of the support of the immersion heater relay concerned.</p> <p>Check the connection on the computer connector and on the support.</p>
<p>If the fault persists following these checks, change the immersion heater relay concerned.</p>

<b>1.cc.1 / 2.cc.1</b>	<b>NOTES</b>	None
------------------------	--------------	------

<p>Measure the resistance of the coil of the relay concerned between <b>terminals 1 and 2</b>.</p> <p>Change the relay if the resistance is not approximately <b>65 ohms</b>.</p> <p>Ensure the insulation from + <b>12 volts</b> of the connection between <b>track 27</b> (relay 1) or <b>track 47</b> (relay 2) of the computer connector <b>track 2</b> of the support of the immersion heater concerned.</p>
<p>If the fault persists following these checks, change the immersion heater relay concerned.</p>

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test.</p> <p>Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	--

<b>DF042 present or stored</b>	<p><u>Fuel flow circuit</u></p> <p>dDEF : Fault stored</p> <p>1.dDEF : Drift when cold</p> <p>2.dDEF : Drift when warm</p> <p>3.dDEF : "Stop" limit not reached</p> <p>4.dDEF : "Starting" limit not reached</p> <p>5.dDEF : Open circuit or short circuit to 12 volts</p> <p>6.dDEF : Short circuit to earth</p>
--	---

<b>NOTES</b>	<p>If fault DF021 co.1 is also present, check the securing of the pump 7-way round connector.</p>
--------------	---

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

Carry out a road test to try to confirm the presence of a fault.  
If the bargraph shows that a fault is present, apply the fault finding procedure associated with the type of fault indicated.

If it is not possible to obtain an indication that a fault is present, switch off the ignition monitoring the diagnostic equipment display during the computer supply maintaining phase.

If it is not possible to obtain a display other than "dEF", there is no fault present on the vehicle. Check the pump wiring and the connections on the 7-way round connector as a precaution.

<b>1.dEF / 2.dEF</b>	<b>NOTES</b>	None
----------------------	--------------	------

Measure the resistance of the flow actuator between **tracks 4 and 7** of the pump connector.  
Change the pump if the resistance is not between **0.4 and 1 ohm at 20°C**.

Ensure the continuity between **tracks 4 / 5 / 49** of the computer connector and **track 4** of the pump connector.  
Ensure the insulation from **earth** and from **12 volts** of this connection.  
Check that **+after ignition** is present on **track 7** of the pump connector.

Check the connections on both connectors of the connection.

If all the checks are positive, reconnect the computer and pump connectors, then erase the computer memory.  
Exit diagnostic mode and carry out a road test. Change the pump if the fault occurs again.

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
---------------------	---

<p><b>DF042</b></p> <p>CONT</p>	
---------------------------------	--

**3.dEF / 4.dEF**

**NOTES**

None

Every time the ignition is switched off, the computer controls the flow actuator to check that the flow regulation slide valve is operating correctly. If the slide valve does not move in line with the request, fault **3.dEF** or **4.dEF** is stored.

Change the diesel injection pump.

**5.dEF / 6.dEF**

**NOTES**

None

Ensure the continuity and insulation of the following connections:

- Between **track 7** of the computer connector and **track 3** of the pump connector.
- Between **track 52** of the computer connector and **track 2** of the pump connector.
- Between **track 29** of the computer connector and **track 1** of the pump connector.

Ensure the insulation between these 3 connections.

Check the connections on both connectors of the connection.

If all the checks are positive, reconnect the computer and pump connectors, then erase the computer memory.

Exit diagnostic mode and carry out a road test. Change the pump if the fault occurs again.

**AFTER  
REPAIR**

Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.



<b>DF045 present or stored</b>	<p><u>Pre-heating relay circuit</u></p> <p>dEF : Fault stored co.0 : Open circuit or short circuit to earth cc.1 : Short circuit to 12 volts 1.dEF : Consistency with diagnostic line return</p>
--	--

<b>NOTES</b>	Check the condition of the 70A fuse in the engine compartment connection unit first.
--------------	--

<b>dEF</b>	<b>NOTES</b>	None
------------	--------------	------

<p>Use the "<b>Pre-heating relay</b>" command to try to confirm the presence of a fault. If the fault is shown to be present on completion of the command, apply the fault finding procedure associated with the type of fault indicated. If it is not possible to obtain an indication that a fault is present, erase the computer memory then switch the ignition off and then on again. Apply fault finding procedure <b>1.dEF</b> below if the fault is shown to be stored again (dEF).</p>	
<p>If it is not possible to obtain an indication that a fault is present, check the heater plugs wiring and the connections on the relay unit as a precaution.</p>	

<b>co.0 / cc.1</b>	<b>NOTES</b>	None
--------------------	--------------	------

<p>Ensure the continuity and insulation of the connection between <b>track 50</b> of the computer connector and <b>track B1</b> of the relay unit connector. Check the connections on both connectors of the connection.</p>	
<p>If the fault persists following these checks, change the relay unit.</p>	

<b>AFTER REPAIR</b>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
-------------------------	---

<p><b>DF045</b></p> <p>cont</p>	
---------------------------------	--

<p><b>1.dEF</b></p>	<p><b>NOTES</b></p>	<p>None</p>
---------------------	---------------------	-------------

<p>Ensure that the 2 connectors on the relay unit are connected. Ensure that all the pre-heating heater plugs are connected.</p>
<p>Ensure the continuity and insulation of the connection between <b>track 30</b> of the computer connector and <b>tracks C1 and C2</b> of the relay unit 6-way connector. Ensure that <b>+after ignition</b> is present on <b>track A1</b> of the relay unit 6-way connector. Ensure that <b>earth</b> is present on <b>track A2</b> of the relay unit 6-way connector. Ensure that <b>+before ignition</b> is present on <b>track 2</b> of the relay unit 3-way connector (70 A fuse). Check the connections on the relay unit and the computer.</p>
<p>Disconnect the pre-heating heater plugs and check/ensure the insulation from earth of the wiring between the relay unit and the pre-heating heater plugs. Check the condition of the heater plugs wiring. Check and change the faulty heater plugs (short circuit).</p>
<p>If the fault persists following these checks, change the relay unit.</p>

<p><b>AFTER REPAIR</b></p>	<p>Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.</p>
----------------------------	---

<b>DF047 present or stored</b>	<u>Supply</u> dEF : Fault stored 1.dEF : Excess battery voltage 2.dEF : Battery voltage low
--	--

<b>NOTES</b>	If appropriate, carry out a complete check of the charging circuit using the Optima 5800 diagnostic equipment.
--------------	--

Carry out the operations necessary to obtain a correct computer supply voltage: <b>6 volts &lt; operating voltage &lt; 16.5 volts.</b> <ul style="list-style-type: none"> <li>- Battery charge check.</li> <li>- Charging circuit check.</li> <li>- Check of the securing and condition of the battery terminals.</li> <li>- Computer earth check.</li> </ul>	
--	--

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
-------------------------	--

<b>DF051 present or stored</b>	<u>Brake pedal switch circuit</u> dEF : Fault stored 1.dEF : Consistency between the two items of brake information 2.dEF : Consistency of the brake signal after starting
--	---

<b>NOTES</b>	None
--------------	------

Monitor statuses **ET013 Brake switch n° 1 information** and **ET014 Brake switch n° 2 information** with the pedal pressed and released.  
During normal operation, both statuses are "not validated" when the pedal is not pressed. They are validated when the pedal is pressed.

Are the "pedal pressed" and "pedal not pressed" statuses of the brake pedal recognised correctly?

<b>YES</b>	There is no brake switch fault. Carry out a simple preventive check of the fitting of the switch and the connection of its connector.
------------	--

<b>NO</b>	Check the condition and setting of the brake switch. Disconnect the brake switch then check/ensure that <b>+after ignition</b> is present on <b>track 1</b> of the connector, wiring end. Check the operation of the brake switch contacts (opening of the contact between <b>tracks 1 and 2</b> and closing of the contact between <b>tracks 1 and 3</b> when the pedal is pressed). Check and ensure the continuity of the following connections: <ul style="list-style-type: none"> <li>- between <b>track 2</b> of the brake switch connector and <b>track 20</b> of the computer connector.</li> <li>- between <b>track 3</b> of the brake switch connector and <b>track 44</b> of the computer connector.</li> </ul>
-----------	---

<b>AFTER REPAIR</b>	Erase the computer memory, switch off the ignition and then carry out a road test. Complete the operation by carrying out a test using the diagnostic equipment.
-------------------------	---

#### REPLACEMENT OF THE COMPUTER

The LAGUNA is fitted with additional immersion heaters as standard.

Depending on the country, this equipment is present on vehicles in the MEGANE range which are fitted with the F9Q 736 engine. When a computer is changed on a MEGANE vehicle, it may be necessary to alter the configuration of the computer using the configuration command "Without immersion heaters" for vehicles which are not provided with immersion heaters (computer pre-configured "With immersion heaters").

The configuration commands with/without Air Conditioning, with/without Variable Power Steering cannot be used on these vehicles (computer configured "with AC" by default, power steering electropump assembly not fitted on these applications).

<b>NOTES</b>	Only carry out this conformity check following a check using the NXR equipment. Engine stopped, ignition on
--------------	--

Order	Function	Parameter / Status checked or action	Display /Notes	Diag.
1		ET 001 + after ignition computer PR 004 Computer supply voltage	Status confirmed  11.8 < X < 13. 2	
2	Warning light on instrument panel	ET 004 Fault warning light ET 008 Over-heating warning light	Status not confirmed  Status not confirmed. Illuminated on the instrument panel for a few seconds when the ignition is switched on	
3	Load potentiometer	ET 016 No-load switch PR017 load potentiometer position	Status confirmed  at no-load = 0 % at full-load = 100 %	
4	Pre-post heating function	Pre-heating / fault warning light	Illuminated on the instrument panel for a few seconds when the ignition is switched on	
5	Immersion heaters operation	ET 031 immersion heaters group 1 relay command ET 032 immersion heaters group 2 relay command	Statuses confirmed in line with operation	
6	Fuel shut-off	ET 033 fuel shut-off relay command	Status not confirmed engine stopped	
	Brake switch	ET 013 brake switch n° 1 information ET 014 brake switch n° 2 information	Statuses confirmed if the brake pedal is pressed	

**Fault finding - Conformity check**

<b>NOTES</b>	Only carry out this conformity check following a check using the NXR equipment. Engine stopped, ignition on
--------------	--

Order	Function	Parameter / Status checked or action	Display / Notes	Diag.
7	Diesel temperature sensor  Coolant temperature sensor  Air temperature sensor  Atmospheric temperature sensor	PR 001 Fuel temperature  PR 002 Coolant temperature  PR 003 Air temperature  PR 016 Atmospheric pressure	- 40°C < X < 140°C  - 32°C < X < 140°C  - 32°C < X < 140°C  420 mbar < X < 1070 mbar	
8		PR 007 intake air flow  PR 011 Idle regulation reference PR035 idle speed correction  PR 012 engine speed seen by the needle lift	X = 450±50 kg/h  X = 850 rpm if X = 0 rpm  X = 0 rpm	
9	EGR function	PR 024 EGR solenoid valve OCR	X = 95 %	
10	Computer configuration (F9Q 736)	Command: reading of immersion heaters option	Only configuration possible	
11	Fan assembly	Command: fan assembly low speed  Command: fan assembly high speed	The fan assembly should be heard running at low speed  The fan assembly should be heard running at high speed	
12	Advance solenoid valve	Command: Advance actuator	The actuator should be heard to knock	

<b>NOTES</b>	Only carry out this conformity check following a check using the NXR equipment. Engine warm, at idle, with no power consuming equipment operating
--------------	--

Order	Function	Parameter / Status checked or action	Display / Notes	Diag.
13	Fuel shut-off	Fuel shut-off command	The actuator should be heard to knock lightly	
14	Fuel shut-off	ET 033 Fuel shut-off relay command	Confirmed	
15	Engine speed sensor	PR 006 Engine speed PR 004 Computer supply voltage	Idle speed 850 rpm $12.5 < X < 15$	
16		ET 033 Fuel shut-off command PR 007 Intake air flow PR 011 Idle regulation reference PR 012 Engine speed seen by the needle lift PR 020 Fuel flow reference	Status confirmed  $X = 50 \pm 20$ kg/h  $X = 850$ rpm  $X = 850$ rpm  $X = 7$ mg/stroke at idle	
17	EGR function	PR 024 EGR solenoid valve OCR	$X = 5\%$ in line with operation of the EGR	
18	AC function	ET 006 Air conditioning request ET 007 Air conditioning authorisation PR 006 Engine speed ET 037 Fan assembly low speed relay command	Statuses confirmed in line with operation of the AC  $X = 875$ rpm  Status confirmed	



<b>NOTES</b>	Only carry out this conformity check following a check using the NXR equipment. Engine warm, at idle, with no power consuming equipment operating
--------------	--

Order	Function	Parameter / Status checked or action	Display / Notes	Diag.
19	Heated windscreen function	ET 015 Heated windscreen information  PR 006 Engine speed	Status confirmed  X = 875 rpm	
20	Fan assembly operation	PR 037 Fan assembly low speed relay command  PR 038 Fan assembly high speed relay command	Status confirmed in line with the operating temperature	

### NOTES

Only refer to these customer complaints after carrying out a complete check using the diagnostic equipment

**NO DIALOGUE WITH THE ENGINE MANAGEMENT COMPUTER**

**CHART 1**

**STARTING PROBLEM (engine does not start or starting is difficult)**

**CHART 2**

**PASSENGER COMPARTMENT HEATING PROBLEM WHEN COLD (engine temperature increase difficulty)**

**CHART 3**

**FLASHING OF THE INJECTION FAULT WARNING LIGHT**

**CHART 4**

<b>CHART 1</b>	<b>NO DIALOGUE WITH THE ENGINE MANAGEMENT COMPUTER</b>
----------------	--

<b>NOTES</b>	None
--------------	------

Ensure that the diagnostic equipment is not the cause of the fault by trying to communicate with a computer on another vehicle. If the equipment is not faulty and dialogue is not established with any other on the same vehicle, it is possible that a faulty computer is causing interference on diagnostic lines **K** and **L**. Locate this computer by disconnecting the computers one by one.

Check the battery voltage and carry out the operations necessary to obtain a specification voltage (6.5 volts < U battery < 16.5 volts).

Check the + **after ignition supply fuse** on the interconnection unit.

Check the connection and the condition of the computer connection connections and of the **R34** engine/instrument panel connection.

Check that the computer is supplied correctly:

- **Earth on tracks 1, 24 and 46** of the computer connector (check the condition and the securing of the engine earth strap and the MH engine earth).
- **+ after ignition on track 38** of the computer connector.

Check that the diagnostic socket is supplied correctly:

- **Earth on track 5.**
- **+ before ignition on track 16.**

Check and ensure the continuity and insulation of the diagnostic socket / computer connection lines:

- Between **track 66** of the computer connector and **track 15** of the diagnostic socket.
- Between **track 61** of the computer connector and **track 7** of the diagnostic socket.

If dialogue is still not established following these checks, check the operation of the main relay:

- Check / ensure that **+before ignition** is present on **terminals 30 and 86** of the main relay support (fuse).
- Remove the relay and check with the ignition on that the computer supplies an earth to **terminal 85** of the relay support (continuity between track 42 of the computer connector and terminal 85).
- Reconnect the relay and check that + after relay is present on **terminal 87**.

If the relay operates correctly, check the continuity between **terminal 87** of the relay support and **tracks 23, 45 and 68** of the computer connector.

If the dialogue is still not established, change the computer.

<b>AFTER REPAIR</b>	When communication is established, deal with any faults which are indicated.
---------------------	--

<b>CHART 2</b>	<b>STARTING PROBLEM</b> (engine does not start or starting is difficult)
----------------	---

<b>NOTES</b>	Only refer to this customer complaint after carrying out a complete check using the diagnostic equipment.
--------------	---

If no faults are indicated by the diagnostic equipment, ensure that the problem is not the result of an engine immobiliser fault.

Check the operation of the pre-heating:  
Use the "**Pre-heating relays**" command and check that there is a voltage on the pre-heating heater plugs.

- If none of the heater plugs are supplied, check the connection of the intermediate 2-way connector and the 3-way connector on the relay unit. Also check the condition of the **70 Amp fuse** on the engine connection unit.
- If only one group of heater plugs is not supplied, check the wiring.

If the fault persists, change the relay unit.

If the problem persists, check the fuel supply circuit (of the pump and the injectors).  
If necessary, carry out a complete check of the engine (starter drive speed, pump setting, condition of the injectors, valve clearances, compressions, ...).

<b>AFTER REPAIR</b>	Carry out a road test then a check using the diagnostic equipment. Deal with any faults indicated.
---------------------	---

<b>CHART 3</b>	<b>PASSENGER COMPARTMENT HEATING PROBLEM WHEN COLD (engine temperature increase difficulty)</b>
----------------	---

<b>NOTES</b>	Only refer to this customer complaint if the vehicle is fitted with immersion heaters and following a complete check using the diagnostic equipment.
--------------	--

Check the operation of the engine cooling circuit immersion heaters:	
Use the " <b>Group 1 immersion heaters relay</b> " then " <b>Group 2 immersion heaters relay</b> " commands and check that there is a voltage on the 3 immersion heaters.	
If there is a fault, check the immersion heaters supply wiring and the operation of the relays. If the 3 immersion heaters are supplied correctly, check the condition of the immersion heaters (resistance= $0.6 \pm 0.1$ ohm at 20°C).	

<b>AFTER REPAIR</b>	Carry out a road test then a check using the diagnostic equipment. Deal with any faults indicated.
---------------------	---

<b>CHART 4</b>	<b>FLASHING OF THE INJECTION FAULT WARNING LIGHT</b>
----------------	--

<b>NOTES</b>	Only refer to this customer complaint following a complete check using the diagnostic equipment. The flashing of the warning light may be the result of a computer with an engine immobiliser code programmed on another vehicle (the computers are not interchangeable).
--------------	---

<p>If no fault is indicated by the diagnostic equipment, the problem is certainly linked to a fault on the coded line which permits operation of the engine immobiliser system.</p> <p>Ensure the continuity and insulation of the connection between <b>track 59</b> of the computer connector and the passenger compartment connection unit.</p>
<p>If the problem persists, refer to the fault finding information in the F9Q engine engine immobiliser information database.</p>

<b>AFTER REPAIR</b>	Carry out a road test then a check using the diagnostic equipment. Deal with any faults indicated.
---------------------	---